

CHANELLE VANITY

INSTRUCTION MANUAL

Five Optional Versions

1. Centre Corner Unit 400mm
 2. Centre Corner Unit 600mm
 3. Corner Unit plus LH Drawers 900 x 600mm
 4. Corner Unit plus RH Drawers 900 x 600mm
 5. Corner Unit plus LH & RH Drawers 900 x 900mm
- Specific Tops supplied to match type of cabinets



0224

IMPORTANT!

1. When you receive your Stein Chanelle Vanity package, please check for any freight damage.
2. If damage has occurred, advise your supplier within 8 hours.
3. Do not install any faulty product as this will invalidate later claims.

AFTERCARE: https://stein.nz/wp-content/uploads/2020/12/STEIN_Aftercare_2020_DEC_RC120220.pdf

PLEASE READ CAREFULLY**WARRANTY**

1. This covers faulty product. Check stein.nz for full details.
2. Any breakage on site will not be covered.
3. The installation must conform to these instructions for the warranty to apply.
4. Compliance with NZ Building code clause G4 on ventilation is required.
5. Compliance with Stein Aftercare guidelines is essential.

https://stein.nz/wp-content/uploads/2020/12/STEIN_Aftercare_2020_DEC_RC120220.pdf

HEALTH AND SAFETY

- Full size vanities are heavy and two-man lifting is recommended.
- Determine positioning of wiring, water, or gas pipes within wall cavity. Mark this position if it applies.

MATERIALS REQUIRED

- Masking tape
- Bathroom Silicone (Wide adhesion features including plastics)
- Cleaning materials
- 75mm screws (Cabinet to Wall)

IMPORTANT NOTICE! (TO BOTH INSTALLER, AND HOUSE OWNER/OCCUPIER)

All personnel have the specific responsibility to protect this Vanity from water damage. Chanelle Vanity surfaces are water resistant, but not classified as waterproof.

Installer

1. If joining Centre Base Unit to drawers, ensure the outer frames are flush as centre cupboard door can catch on the drawers if not aligned correctly.
2. Remove cupboard and drawers for better access for waste and pipe installation.
3. Tiling must be completed and prior to Vanity installation. The warranty doesn't include restoration of tiling or wall finishing.
4. Avoid any distortion to the cabinet due to wall discrepancies as this will cause the door and drawers to be misaligned. Offset discrepancies with packers if needed.
5. Fit the top in place. This should be flush at the back with even overlaps on each side. Bond the top down with silicone using any packing if there is rocking movement.
6. All joints in cabinet and cabinet to wall, floor and top must be sealed.

House Owner/Occupier

1. When moisture is present in the bathroom, ventilation must be activated.
2. Water from cleaning or spills must be dried off without delay.

CONTACT**STEIN**

54 Unutoto Place, Tauriko, Tauranga, 3171

Freephone: 0800 002 299

Phone: 07 928 9990

Email: info@stein.co.nz

stein.nz